

INSTALLATION INSTRUCTIONS FOR THE RKBC LED RETROFIT KIT

APPLICATION: General/Perimeter Lighting

MOBERN
L I G H T I N G



← Strip fixture with T8 bulbs and ballast

- 1- Turn off power
- 2- Remove ballast/wireway cover from existing strip fixture



- 3- Remove lampholders and socket bars from existing strip housing
- 4- Remove ballast



4RB – 4ft LED retrofit kit →



- 5- Place RKBC LED board and wired driver wirecover on appropriate existing 4' or 8' channel

- 6- Install supplied screw(s) in slot(s) on both ends and each side of new wireway cover into side of existing channel. For 8' channel also install screw(s) in center side slots
- 7- Turn on power

